


20 BARON



Teiliste					Parts List				
Nr.	Teil	Menge	Name	Quan	Nr.	Teil	Menge	Name	Quan
B 20-101	Rahmenträger (L. R.)	je 1	Sub Frame (L. R.)	1ea	3851-0101				
1-02	Winkelblech	2	Servo Plate Retainer	2	-0102				
1-03	Querstrebe vorn	1	Cross Member (A)	1	-0103				
1-04	Befestigungsbolzen, vorn	1	Body Mounting Bolt (F)	1	-0107				
1-05	Bodenplatte	1	Front Bed	1	-0623				
1-06	Seitenblech (L. R.)	je 1	Main Frame (L. R.)	1ea	-0106				
1-07	Befestigungsbolzen, oben	2	Body Mounting Bolt (R)	2	-0107				
1-08	Stützhebel	1	Radius Support Arm	1	-0108				
1-09	Querstrebe, hinten	1	Cross Member (B)	1	-0109				
1-25	Schraubensatz Nr. 1	1	No. 1 Screw Set	1	-0125				
2-01	Ritzel	1	Pinion Gear	1	3851-0201				
2-02	Kuppungsglocke	1	Clutch Bell	1	-0202				
2-03	Lager	1	1980 Ball Bearing	1	-0203				
2-04	Lager	2	1980 Ball Bearing	2	-0204				
2-05	Lagergehäuse	10	Bearing Case	10	-0205				
2-25	Schraubensatz Nr. 2	1	No. 2 Screw Set	1	-0225				
3-01	Drosselhebel OS	1	Throttle Lever for OS	1	3851-0301				
3-02	Drosselhebel ENYA	1	Throttle Lever & Spacer for ENYA	1ea	-0302				
3-03	Lüfterrad	1	Cooling Fan	1	-0303				
3-04	Riemenscheibe	1	Pulley	1	-0304				
3-05	Kuppung	1	Clutch (w/ pilot bearing)	1	-0305				
3-06	Motorblock	1	Engine Mounting Block	1	-0306				
3-07	Getriebsgehäuse	1	Cooling Shroud	1	-0307				
3-08	Anlaßriemen	1	Starting Belt	1	-0308				
3-25	Schraubensatz Nr. 3	1	No. 3 Screw Set	1	-0325				
4-00	Pitchgestänge	1	Pitch Slide Rod	1	3851-0400				
4-01	Pitchhebel	1	Slide Ring Assembly	1	-0401				
4-02	Pitchhebelstager	1	Slide Ring Pivot	1	-0402				
4-03	Pitchsteuerung, oben	1	Pitch Control Ring	1	-0403				
4-04	Milzennaher	1	Upper Plate Lock	1	-0404				
4-05	Hauptrotorwelle CP	1	Main Shaft CP	1	-0405				
4-06	Taumscheibe	1	Swash Plate CP	1	-0406				
4-07	Buchse	1	Swash Plate Collar	1	-0407				
4-08	Hauptzahnrad	1	Main Gear	1	-0408				
4-09	Kugellager	2	1450 Ball Bearing	2	-0409				
4-10	Kegelzahnrad	1	Bevel Pinion Gear	1	-0410				
4-11	Hauptrotorwelle FP	1	Main Shaft FP	1	-0411				
4-12	Taumscheibe FP	1	Swash Plate FP	1	-0412				
4-25	Schraubensatz Nr. 4 CP	1	No. 4 Screw Set CP	1	-0425				
4-26	Schraubensatz Nr. 4 FP	1	No. 4 Screw Set FP	1	-0426				
5-01	Kufenstrebe	2	Under Carriage Braca	2	3851-0501				
5-02	Kufenhalter	4	Under Carriage Clamp	4	-0502				
5-03	Kufen	2	Under Carriage Skid	2	-0503				
5-04	Tank	1	Fuel Tank	1set	-0504				
5-25	Schraubensatz Nr. 5	1	No. 5 Screw Set	1	-0525				
6-01	Heckrotorgehäuse (A, B)	je 1	Tail Gear Housing (A, B)	1ea	3851-0601				
6-02	Gehäusering	1	Tail Gear Housing Ring	1	-0602				
6-03	Heckrotorwelle Eingang	1	Tail Input Gear	1	-0603				
6-04	Heckrotorwelle Ausgang	1	Tail Output Gear	1	-0604				
6-05	Kugellager	3	1050 Ball Bearing (open)	3	3851-0605				
6-06	Kugellager, geschlossen	1	1050 Ball Bearing (sealed)	1	-0606				
6-07	Heckrotormittelstück mit Kugellager	1	Tail Rotor Hub w/ ball bearing	1	-0607				
6-08	Blatthalter für Heckrotor	1	Tail Rotor Grip	1set	-0608				
6-09	Steuerhebel für Heckrotor	1	Tail Pitch Control Plate	1	-0609				
6-10	Lagerbock für Heckrotor	1	Tail Pitch Control Bracket	1	-0610				
6-11	Umlenkhebel für Heckrotor	1	Tail Pitch Control Crank	1	-0611				
6-12	Steuergehänge für Heckrotor	1	Tail Pitch Control Lever	1	-0612				
6-13	Stellring	2	Tail P.C. Plate Retainer	2	-0613				
6-14	Heckwelle	1	Tail Drive Music Wire	1	-0614				
6-15	Wellenkuppung	2	Tail Joint	2	-0615				
6-16	Zentrierbuchse	2	Tail Joint Spacer	2	-0616				
6-17	Heckrohr	1	Tail Boom	1	-0617				
6-18	Wellenlager	1	Tail Drive Wire Guide	1	-0618				
6-19	Rotorscheiben	4	Tail Clamping	4	-0619				
6-20	Rohrhalter	2	Tail Boom Retainer	2	-0620				
6-21	Heckrotorstütze	1	Tail Boom Support	1set	-0621				
6-22	Seitenfederflosse	1	Vertical Fin	1	-0622				
6-23	Höhenfederflosse	1	Horizontal Stabilizer	1	-0623				
6-24	Heckrotorblatt	1	Tail Rotor Blade	1set	-0624				
6-25	Schraubensatz Nr. 6 CP	1	No. 6 Screw Set CP	1	-0625				
6-26	Schraubensatz Nr. 6 FP	1	No. 6 Screw Set FP	1	-0626				
7-01	Servoplatte (A, B)	je 1	Servo Mounting Bed (A, B)	1ea	3851-0701				
7-02	Hotzträger	1	Servo Mounting Bed Stock	1	-0702				
7-03	Umlenkhebelset	2	Bell Crank, Spacer, Washer	2ea	-0703				
7-04	Bowdenzug, innen	1	Flexible P.P. Rod	1set	-0704				
7-05	Bowdenzug, außen	1	Flexible P.P. Rod Bracket	1	-0705				
7-25	Schraubensatz Nr. 7 CP	1	No. 7 Screw Set CP	1	-0725				
7-26	Schraubensatz Nr. 7 FP	1	No. 7 Screw Set FP	1	-0726				
8-00	Rotorkopf CP	1	Rotor Head Assembly CP	1	3851-0800				
8-01	Rotorkopf FP	1	Rotor Head Assembly FP	1	-0801				
8-02	Hilfsrotorstange	1	Stabilizer Bar	1	-0802				
8-03	Hilfsrotorblatt	2	Stabilizer Blade	2	-0803				
8-04	Stellring	1	Stabilizer Retainer	1	-0804				
8-05	Steuerhebel CP	1	Control Lever CP	1	-0805				
8-06	Hauptrotorblatt CP	1	Main Rotor Blade CP	1set	-0806				
8-07	Blattverstärkung CP	2	Main Rotor Blade Reinforcement	2	-0807				
8-08	Steuerhebel FP	1	Control Lever FP	1	-0808				
8-09	Hauptrotorblatt FP	1	Main Rotor Blade FP	1set	-0809				
8-10	Abstandsring	2	Hub Spacer	1	-0810				
8-11	Blatthalter	4	Blade Holder	1	-0811				
8-12	Anstellwinkelhebel	1	Pitch Gauge	1	-0812				
8-25	Schraubensatz Nr. 8 CP	1	No. 8 Screw Set CP	1	-0825				
8-26	Schraubensatz Nr. 8 FP	1	No. 8 Screw Set FP	1	-0826				
9-01	Kabine (L, R) Instrumentenbrett	1	Cabin (L, R) Instrument Panel	1ea	3851-0901				
9-02	Flüssiggleiter	1	Liquid Glue for A.B.S.	1	-0902				
9-03	Kabinenscheibe	1	Canopy	1	-0903				
9-25	Schraubensatz Nr. 9 CP	1	No. 9 Screw Set CP	1	-0925				
9-26	Schraubensatz Nr. 9 FP	1	No. 9 Screw Set FP	1	-0926				
Steuergehänge Set	1 Satz	Linkage Set	1set	3851-3001					
Kugellager	1	Universal Link with ball	1	-3002					
Plan	1	Construction Drawing	1						
Montageanleitung	1	Instruction Manual	1						
1	Autoprotationsfreilauf	autorotation system	1	3852					
2	Hauptzahnrad	main gear for autorotation	1	3852-1000					
3	Hauptrotorwelle	main shaft for autorotation	1	-3000					
4	Freilaufbuchse	autorotation gear shaft	1	-3000					