




201 S. 3rd. Street & 309 N.
Coopersburg, PA. 18036
Phone: (610) 282-4811
E-mail: hhi@fast.net



Q-16 PRO HEAD BOM

ITEM NO.	QTY.	PART NO.	DESCRIPTION	ITEM NO.	QTY.	PART NO.	DESCRIPTION
1	2	QH161	FLYBAR CONTROL ARM ASSY	17	2	BRG05114R	5x11x4 REGULAR BEARING
2	1	QH144	FLYBAR CONTROL ARM BASE	18	2	HHI3M5FW	3x5x0.5 FLAT WASHER
3	1	QH145	FLYBAR CONTROL ARM EXTENTION	19	1	HHI3M20C	DIN912-12-M3x20 SHCS
4	1	HHI3M08C	DIN912-12-M3x8 SHCS	20	2	HHI3M30C	DIN912-12-M3x30 SHCS
5	1	HHI4M04SS	M4x4 SET SCREW	21	2	HHI3M4PS	M3x4 PIVOT BALL STUD
6	2	QH163	FLYBAR PADDLE BLACK POLY	22	1	QH350	HEAD SPINDLE 8x97mm (STEEL)
7	4	QHL354	HEAD SPINDLE O-RING	23	2	QH558	PRO BLADE GRIP
8	1	QUI5P14	FLYBAR 3x390mm (STEEL)	24	2	QH554	PRO BLADE GRIP PITCH ARM
9	2	HHI3M8PS	M3x8 PIVOT BALL STUD	25	2	QH556	PRO HEAD THRUST BRG SPACER
10	8	HHI3M10C	DIN912-12-M3x10 SHCS	26	4	QH603	PRO BLADE GRIP SLEAVE
11	3	HHI03MLN	3mm NYLON LOCK NUT	27	4	BRG08165R	8x16x5 REGULAR BEARING
12	1	QH331A	HEAD CENTER HUB	28	2	HHI4M08F	M4x8 FHCS
13	1	QH340A	12x3x57mm SEESAW	29	2	QC150B	ANTI-ROTATION WASHOUT GUIDE PIN 2x21mm
14	2	BRG08165T	8x16x5 THRUST BEARING	30	2	QH152	HILLER ARM
15	2	QHL353	HEAD SPINDLE SPACER	31	2	QC556	DOUBLE-LINK (BLACK)
16	6	BRG03073R	3x7x3 REGULAR BEARING	32	2	HHI3M5X1	HEAD ASSY SPACER 3x5x1mm