


AIR WOLF INSTALLATION MANUAL


ENGINE SIZE:50


NOTICE: USE EPOXY UNLESS STATED.
SAND INSIDE FUSELAGE WITH #180 SANDING
PAPER BEFORE PARTS GLUING IN PLACE.
























AIR WOLF INSTALLATION MANUAL


ENGINE SIZE:50























AIR WOLF


ENGINE SIZE:50


INSTALLATION OF RETRACTABLE LANDING GEAR






















AIR WOLF


ENGINE SIZE:50

INSTALLATION OF CENTURY SCALE SE MECHANISM




















MESH TEMPLATE (SCALE 1:1) FOR BELL 222 (50) / AIR WOLF (50)

